



# FLOORLEUM FLAKE NW

category: vinyl sheet

Various sizes of beautiful chip patterns are overlapped in "FLAKE NW".

Specification	overall thickness	2.0mm	width x length	1820mm x 9m
	others	Antibacterial Finished / Highly Durable UV-Coated Surface		
JIS Registered No.	No. GB0506143 (JIS A 5705 Vinyl Sheet Flooring)			
Packing	9m/roll			
Net Weight	45.9kg/roll			
Recommended Adhesive from TOLI	dried mortar and concrete	Eco Royal Cement, Eco AR600		
	The wards and living rooms where beds with double-row casters are used	Epo GrayST, US Cement, US Cement (less-smelly)		
	humid mortar and concrete	Epo Gray ST, US Cement, US Cement (less-smelly)		
	TOLI UNDERLAY SHEET	US Cement, US Cement (less-smelly), US200		
Welding	◆Welding rod for heat-welding is available on a color-by-color basis.			
Notes on Installation	<ul style="list-style-type: none"> <li>◆Seams should be heat-welded or finished with TOLI JOINT SHIELD.</li> <li>◆TOLI JOINT SHIELD can also work on the top of TOLI UNDERLAY SHEET, but when partial weight will be put on the floor (such as heavy stuff or casters), the seam joints should not be finished with TOLI JOINT SHIELD.</li> <li>◆When you install 2 different sheets, each edge should be jointed at the seam. (Do not cut in the middle of the sheet.)</li> <li>◆For one week after installation, direct sunlight, sudden change of temperature due to air conditioning, and water washing should be avoided.</li> <li>◆Please do not use the urethane adhesive other than US Cement, US Cement (less-smelly). (except using TOLI UNDERLAY SHEET)</li> <li>◆As the sub-floor material, the underlayment like TOLI UNDERLAY SHEET (page 286) is also workable. Apply the same adhesive for both upside and downside of the underlayment.</li> </ul>			
Recommended Way of Maintenance from TOLI	<ul style="list-style-type: none"> <li>◆No need to apply the maintenance wax on the surface. Clean the floor every day with an auto scrubber or a wet rag wrung out tightly. Use the detergent for fixed contamination.</li> <li>◆Even if the wax is applied on the surface, it does not affect the quality of NW series.</li> <li>◆For a large facility, an abstergent auto scrubber is more recommendable.</li> <li>◆High speed buffing should be avoided. Otherwise highly durable UV coating will be abraded.</li> </ul>			
Others	<ul style="list-style-type: none"> <li>◆At the entrance of the building, the dust control mat should be laid in order to avoid soils and sands from outside.</li> <li>◆To prepare the floor which is durable to rolling loads, please fully check the combination of HOSPILEUM NW and the sub-floor, the adhesive, and the loads. For instance, when the sub-floor is too weak, HOSPILEUM NW might be destroyed from underneath.</li> <li>◆The dirt and stains will be more visible on the floor covering with lighter plain colors, compared to dark colors. Also they are more likely to stick with the deep-embossed surface than the flat surface.</li> <li>◆Please be aware that some rubber casters might cause color-contamination.</li> <li>◆Please note that the product has the indigenous odor from its materials.</li> </ul>			

Vinyl Sheet


MADE IN JAPAN



20FL901



20FL902



20FL904



20FL903



20FL904



20FL908



20FL909



20FL905



20FL906



20FL907