



UNDERLAY
T11
Technik Line
Hardwood Floors



NATURE'S IMPACT NOISE REDUCTION UNDERLAY

- Installed Directly under the Final Floor
- High Walking Comfort with Reduced Thickness
- High Durability and Long Term Resilience
- 100% Natural and Sustainable Product

PRODUCT DESCRIPTION

Agglomerated Cork Underlay for Impact Noise and Thermal Insulation of Hardwood Floors.

THERMAL PROPERTIES (ISO 8301)

Thermal Conductivity:
0,038 W/m²K

Thermal Resistance:
0,079 m²°K/W

PHYSICAL AND MECHANICAL PROPERTIES (ISO 7322)

Specific Weight: 150-200 Kg/m³
Tensile Strength: > 200 KPa
Compression: 30%
Recovery: > 90%
Durability: Lifetime of the Building

ACOUSTICAL RESULTS (ISO 140 & 717)

$\Delta L_w = 26\text{dB}$
(SRL C/06/5L/3676/1a)

PACKAGING*

1m x 15m x 3mm

* Others sizes available upon request



AMORIM
Amorim Cork Composites

AcustiCORK[®]
UNDERLAY

UNDERLAY

T11

Technik Line
Hardwood Floors



NATURE'S IMPACT NOISE REDUCTION UNDERLAY

General installation instructions

The following installation instructions are recommended by Amorim Cork Composites, but are not intended as a definitive project specification. They are presented in an attempt to be used with recommended installation procedures of the flooring manufacturers.

Room conditions

Temperature > 10°C / Room moisture content < 75%.

Subfloor

All subfloor work should be structurally sound, clear and level. The moisture content of the subfloor should not be more than 2.5% (CM) by weight measured on concrete subfloors.

Perimeter insulation barrier

Install a perimeter insulation barrier minimum 35mm wide vertically around the entire perimeter of the room. This is highly recommended in order to avoid lateral propagation of impact noise. Spot adhere the strips to the wall using acrylic glue or a bead of silicone sealant (do not forget the edges of pipes, ducts, etc). Before the installation of the skirting boards, the insulation strips must be leveled (trimmed) to the height of the wood.

Installations instructions for AcoustiCORK T11

Unpack the AcoustiCORK T11 at least 24h before the installation and store it in the room where the installation will take place. Use a properly sized V-notched trowel and acrylic glue to glue the AcoustiCORK T11 to the concrete slab. Always follow the glue manufacturers recommended instructions.

Cut the AcoustiCORK T11 to the desired length and install directly over the subfloor with crown of the rolled materials up, removing all trapped air. Butt the AcoustiCORK T11 directly against the insulation perimeter barrier already installed. Put the loose laid material back. Using a properly sized V-notched trowel, apply acrylic glue to the concrete slab. Gently, return the pulled back material to its measure place and roll in both directions with a roller. Proceed to cover the entire floor making sure that the joints are butted tight. After completion, the AcoustiCORK T11 should cover the entire flooring area without gaps and with joints securely taped.

Final flooring

Use polyurethane based adhesive. Always follow manufacturers recommended installation instructions.

Important notes

Never mechanically fasten the AcoustiCORK T11 to the flooring floor as this will severely diminish its acoustical value.

For detailed installation instructions, please contact:

Total Vibration Solutions Ltd

Unit 9, The Courtyard, Grane Road, Haslingden,
Rossendale, Lancashire BB4 4QN
United Kingdom

Tel: +44(0) 1706 260 220

E-mail: info@totalvibrationsolutions.com

Web: www.totalvibrationsolutions.com



NOISE & VIBRATION CONTROL SPECIALISTS
SURVEYS • CONSULTANCY • MATERIALS • INSTALLATION

www.acousticork.eu

HEAD OFFICE

Rua de Meladas, 260 - Apartado 1
4536-902 Mozelos VFR - Portugal
T: +351 22 747 5300 / F: +351 22 747 5301
E-mail: acousticork.acc@amorim.com
www.corkcomposites.amorim.com



União Europeia

Fundo Europeu de
Desenvolvimento Regional

